

ADAM 4000 Series

**Data Acquisition Modules
User's Manual**

ADAM 4000 Series

Data Acquisition Modules

User's Manual

Copyright Notice

This document is copyrighted, 1997, by Advantech Co., Ltd. All rights are reserved. Advantech Co., Ltd., reserves the right to make improvements to the products described in this manual at any time without notice.

No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of Advantech Co., Ltd. Information provided in this manual is intended to be accurate and reliable. However, Advantech Co., Ltd. assumes no responsibility for its use, nor for any infringements upon the rights of third parties which may result from its use.

CE Notification

The ADAM-4000 series developed by Advantech Co., Ltd. has passed the CE test for environmental specifications when operated within an industrial enclosure (ADAM-4950-ENC). Therefore, in order to protect the ADAM modules from being damaged by ESD (Electric Static Discharge), we strongly recommend that the use of CE-compliant industrial enclosure products when using any ADAM module.

Acknowledgments

ADAM is a trademark of Advantech Co., Ltd.
IBM and PC are trademarks of International Business
Machines Corporation.

Part No.2000000220
Printed in Taiwan

5th Edition
March 1997

Table of Contents

Chapter 1 Introduction	1-1
1.1 Overview	1-2
1.2 Applications	1-4
Chapter 2 Installation Guideline	2-1
2.1 System Requirements to Setup an ADAM network	2-3
2.2 Basic configuration and hook-up	2-6
2.3 Baud rate and Checksum	2-9
2.4 Multiple Module Hookup	2-11
2.5 Application Example	2-12
Chapter 3 I/O Modules	3-1
3.1 ADAM-4011/4011D/4012/4013 Analog Input Modules	3-2
3.2 ADAM-4014D Analog Input Module with LED Display	3-12
3.3 ADAM-4016 Strain Gauge Input Module	3-19
3.4 ADAM-4017/4018/4018M 8-channel Analog Input Modules	3-24
3.5 ADAM-4021 Analog Output Module	3-29
3.6 ADAM-4050/4052/4053 Digital I/O Modules	3-32
3.7 ADAM-4060 Relay Output Module	3-39
3.8 ADAM-4080/4080D Counter/Frequency Input Modules	3-41
Chapter 4 Command Set	4-1
4.1 Introduction	4-2
4.2 Syntax	4-2
4.3 I/O Module Commands Search Table	4-4
4.4 Analog Input Module Command	4-35
4.4.1 Analog Input Command Set	4-35
4.4.2 Data Conversion and Display Command Set	4-59
4.4.3 Analog Input Data Logger Command Set	4-71
4.4.4 Digital I/O, Alarm and Event Command Set	4-85
4.4.5 Excitation Voltage Output Command Set	4-101

4.5 Analog Output Module Command	4-109
4.6 Digital I/O and Relay Output Module Command	4-127
4.7 Counter/Frequency Module Command	4-143
4.7.1 Configuration, Counter Input and Display Command Set	4-143
4.7.2 Counter Setup Command Set	4-155
4.7.3 Digital Filter and Programmable Threshold Command Set	4-165
4.7.4 Digital Output and Alarm Command Set	4-177
Chapter 5 Calibration	5-1
5.1 Analog Input Module Calibration	5-2
5.2 Analog Input Resistance Calibration	5-7
5.3 Analog Output Calibration	5-9
Appendix A Technical Specifications	A-1
A.1 ADAM-4011 Thermocouple Input Module	A-2
A.2 ADAM-4011D Thermocouple Input Module with LED Display	A-5
A.3 ADAM-4012 Analog Input Module	A-8
A.4 ADAM-4013 RTD Input Module	A-10
A.5 ADAM-4014D Analog Input Module with LED Display	A-12
A.6 ADAM-4016 Strain Gauge Input Module	A-14
A.7 ADAM-4017 8-channel Analog Input Module	A-16
A.8 ADAM-4018 8-channel Analog Input Module	A-18
A.9 ADAM-4018M 8-channel Analog Input Data Logger	A-21
A.10 ADAM-4021 Analog Output Module	A-24
A.11 ADAM-4050 Digital I/O Module	A-26
A.12 ADAM-4052 Isolated Digital Input Module	A-28
A.13 ADAM-4053 16-channel Digital Input Module	A-30
A.14 ADAM-4060 Relay Output Module	A-32
A.15 ADAM-4080 Counter/Frequency Input Module	A-34
A.16 ADAM-4080D Counter/Frequency Input Module with LED Display	A-36
Appendix B Data Formats and I/O Ranges	B-1
B.1 Analog Input Formats	B-2
B.2 Analog Input Ranges	B-8
B.3 Analog Output Formats	B-13
B.4 Analog Output Ranges	B-15

Appendix C Technical Diagrams C-1

C.1 ADAM Dimensions C-2

C.2 Installation C-3

Appendix D Utility Software D-1

D.1 ADAM Utility Software D-1

D.2 ADAM-4018M Utility Software D-7

Appendix E RS-485 Network E-1

E.1 Basic Network Layout E-2

E.2 Line Termination E-5

E.3 RS-485 Data Flow Control E-8

Appendix F How to use the Checksum features F-1

F.1 Checksum Enable/Disable F-2